

Dimensional Innovations

3421 Merriam Drive
Overland Park, Kansas 66203
913.384.3488 | dimin.com

HOW TO CLEAN A TOUCHSCREEN

Avoid all cleaners with Ammonia!

Use a 50/50 mixture of isopropyl alcohol and water or a non-abrasive use LCD screen cleaner or LCD wipes, which are available at most electronics stores. Do not use any vinegar-based, or ammonia-based solutions (No Windex!)

- Apply the cleaner with a clean soft cloth.
- Always dampen the cloth and then clean the screen.
- Always handle the touchscreen with care. Do not pull on or stress the cables.
- Do not let cleaner seep into the display, as it may cause electrical shock or damage.

The following items can be **safely** used to clean Planar EP/QE models:

- Quaternary ammonium (Virex, PDI Sanicloth HB)
- Bleach 5.25% or 6.25% at (1:10 dilution-1:100)
- Quaternary ammonium in combination with 70% alcohol (iso or ethanol) (PDI Sanicloth or PDI Super Sanicloth)

TECHNOLOGY SUPPORT

Let us know if you have any questions.
support@dimin.com | 913.744.2111